





GETTING TO KNOW THE BAG PHONE




GETTING STARTED




Insert the SIM card:




Straighten the Swivel Antenna:



Connect the Car Lighter or Wall Socket power adaptor to the Connector Panel (the bag phone contains a battery for backup use):



Turn your phone ON:



Motorola M900BP
GSM Bag Phone

Short User's Guide

ANYWHERE MOTO
www.hellomoto.com




6889192v45

GETTING TO KNOW THE M900





INITIAL SET-UP


POWER CONTROL


Turning On/Off Press and hold the Power Key  until the display panel lights on/off.

VOLUME CONTROL



Ring Tone Volume When no call is active, press either of the Volume Keys  on the side of the phone to adjust the volume.



Call Volume During a call press either of the Volume Keys  on the side of the phone to adjust the volume.

Muting Microphone During a call, press the Right Soft Key  to mute.

Key Volume Press Menu Key , scroll down to settings, ring styles, ring detail, key volume.



OTHERS



Letter Size To enlarge characters or numbers on the display, press Menu Key , briefly and then press and hold Menu Key  again.


Display Backlight and Contrast Press Menu Key , and select settings. Select other settings, then initial setup, then select backlight or contrast and use 4 Way Navigation Key  to adjust. Press OK to finish.

CALL MANAGEMENT


PHONE CALLS


Answering a Call Press Send Key  or press Voice Key .


Ending a Call Press End Key  or press Voice Key .



Making a Call Dial the phone number including area code and press Send Key .

VOICE ACTIVATION


Name Dialing Press Voice Key  once and say the name as was recorded (see Basic Operations).

Number Dialing Press Voice Key  twice and say the phone number (initial recording is not required).

Speed Dial Press Voice Key  twice, say the digits of the phonebook entry and then say "pound".

Menus Press Menu  Key and then press Voice Key . Say shortcut name as was recorded (see Basic Operations).




RECENT CALLS

Received/Dialed Calls Press upper/lower arrow of the 4 Way Navigation Key  for received/dialed last calls.



BASIC OPERATIONS

KEYPAD SHORTCUTS



Using Shortcuts

- For your own private Menu press My Menu feature, scroll down, press New and follow instructions.
- For Phonebook press Left Soft Key .
- For Web Browser press and hold upper arrow of the 4 Way Navigation Key .
- For Voicemail press and hold Key #1 .

Creating Shortcuts to your own private Menu

- Select the item you want to add; press and hold Menu Key . You'll be asked to confirm the shortcut; press Yes. Select Key Shortcut and then Voice in order to record Voice Shortcut.
- For menu shortcut activation press Menu Key  and then the allocated menu number or use the voice activation feature.

PHONEBOOK MEMORY

Storing a New Number Enter the phone number and press Right Soft Key  (Store), then scroll to select details: Name, Number, Type and Voice Name (for voice activation). Select More if you want to create another contact under the same name. Press Left Soft Key  (Done) to finish.

Advanced Search Enter phonebook menu, select Search, enter character(s) and press OK.

Speed Dial Enter the digits from the stored phone memory entry you want to call and hold the last digit continuously until the number dials.

* Various phone menus and features are operator dependent